


301
Tapajuntas




302
Tapajuntas Clipado




E342700




E1009500




303
Tapajuntas



304
Tapajuntas Clipado




V1930000




V1940000

Grapa aluminio
tapajuntas frontal


Grapa plástico
tapajuntas frontal




GRAPA V1680200




34
Tapajuntas 37




33
Tapajuntas 37 Clipado




336
Tapajuntas 60



341
Tapajuntas 43 mm.
Clipado




342
Tapajuntas 63 mm.
Clipado




343
Tapajuntas 93 mm.
Clipado




E262200




344
Tapajuntas 30 mm.
Clip Frontal




345
Tapajuntas 50 mm.
Clip Frontal




346
Tapajuntas 80 mm.
Clip Frontal






E262200




E342700




E690200 CHAPA






E630900 FUJI



E690200 CHAPA
E630900 FUJI












E262200



E282200





GRAPA ALU. TAPAJUNTAS FRONTAL

